



---

## Using Thermoelectric Coolers to Enhance Loop Heat Pipe Performance

Jentung Ku  
Dan Butler  
Laura Ottenstein  
NASA Goddard space Flight Center  
301-286-3130  
[Jentung.Ku-1@nasa.gov](mailto:Jentung.Ku-1@nasa.gov)

Gajanana Birur  
Jet Propulsion Laboratory

16<sup>th</sup> Spacecraft Thermal Control Workshop  
El Segundo, California, March 9-11, 2005



# Outline

---



- LHP Operating Temperature
- LHP Start-up Issues
- How TECs Can Enhance LHP Performance
  - Start-up
  - Operating Temperature Control
- Experimental Studies
  - LHP with One Evaporator and One Condenser
  - LHP with Two Evaporators and Two Condensers
- Conclusions



# LHP Operating Temperature

## One Evaporator and One Condenser


- The LHP operating temperature is governed by the CC temperature.
  - Heat leak from evaporator to CC
  - Subcooling of returning fluid
  - Interaction between CC and ambient
- The CC temperature is a function of
  - Evaporator power
  - Condenser sink temperature
  - Ambient temperature





## LHP Operating Temperature Control



- State-of-the-art LHPs use electrical heaters to control the CC temperature.
  - Cold biased
  - Heating only, no active cooling
- TECs provide cooling as well as heating.
  - Cooling mode: expands temperature control to low power region
  - Heating mode: reduces control heater power requirement











# LHP Start-up Scenarios





(a) Situation 1



(c) Situation 3



(b) Situation 2



(d) Situation 4



## LHP Start-up Issues and TEC Solutions Situation 4

- Without TEC (Figure A)
  - CC temperature rises with evaporator temperature due to heat leaks.
  - Required superheat may never be attained at low powers.
  - Starter heaters have been used to provide a highly concentrated heat flux for local boiling – 20W to 40W is required.
- With TEC (Figures B and C)
  - TEC can maintain a constant CC temperature to achieve the required superheat, resulting in a successful start-up.
  - TEC can also cool the CC to create the required superheat.
  - Starter heaters can be eliminated.




Figure A




Figure B




Figure C



## LHP Start-up Issues and TEC Solutions Situation 2

- Without TEC (Figure A)
  - Flow circulation starts after evaporator temperature rises above CC set point.
  - However the CC temperature may rise with evaporator temperature due to heat leaks.
  - Net heat load to evaporator decreases, leading to ever-increasing CC temperature, possibly violating the instrument maximum allowable temperature.
- With TEC (Figures B and C)
  - TEC can maintain a constant CC temperature, ensuring successful start-up and attainment of a steady state.
  - TEC can also cool the CC to start the loop.
  - Starter heaters can be eliminated.




Figure A




Figure B




Figure C



## Experimental Studies with Two LHPs

---

- **Objectives**
  - Demonstrate that TECs can be used to enhance LHP start-up success
  - Demonstrate that TECs can be used to control the CC temperature with small control powers
- **Thermacore Miniature LHP**
  - Single evaporator and single condenser
  - Evaporator size: 7mm O.D. x 50mm L
  - Tests performed with 0g, 117g, and 350g of thermal masses attached to the evaporator
- **MLHP**
  - Two evaporators and two condensers
  - Evaporator size: 15mm O.D. x 76mm L
  - Tests performed with 500 g thermal mass attached to each evaporator







## Design Summary of Thermacore Miniature LHP

Item	Description
Evaporator	Aluminum Shell 7 mm O.D. x 51 mm L
Primary Wick	SS, 5.6 mm O.D. x 2.4 mm I.D 1.2 $\mu$ m pore size, 1.0 x 10 <sup>-14</sup> m <sup>2</sup> permeability
Secondary Wick	SS screen, 400 x 400 mesh
Compensation Chamber	SS 9.52 mm O.D. x 25.5 mm L
Vapor Line	SS, 1.59 mm O.D. x 560 mm L
Liquid Line	SS, 1.59 mm O.D. x 635 mm L
Condenser	Aluminum 2.39 mm O.D. x 200 mm L
Working Fluid	Ammonia, 1.5 grams
Total mass	79 grams




# **Pictures of Thermacore Miniature LHP One Evaporator and One Condenser**





# Schematic of Thermacore Miniature LHP



# MLHP Design Parameters


## Two Evaporators and Two Condensers

Component	Description
Evaporator (2)	Aluminum, 13mm O.D. x 76.2mm L each
Primary wick	Nickel, 0.6 $\mu\text{m}$ pore radius, 60% porosity, $1.4 \times 10^{-14} \text{ m}^2$ permeability
Primary wick	Titanium, 3 $\mu\text{m}$ pore radius, 60% porosity, $1.0 \times 10^{-14} \text{ m}^2$ permeability
CC (2)	Stainless steel, 18mm O.D. x 61mm L, 18cc each
Vapor line	Stainless steel, 2.38mm O.D. x 1200mm L
Liquid line	Stainless steel, 1.59mm O.D. x 1200mm L
Condenser (2)	Stainless steel, 2.38mm O.D. x 760mm L each
Flow regulator	Polyethylene wick, 40 $\mu\text{m}$ pores
Working fluid	Anhydrous ammonia, 15.5 grams






## **MLHP Picture** (with Thermal Masses and TECs)







# MLHP Schematic

## Two Evaporators and Two Condensers






# TEC Connections





# MLHP Test Results - Star-up (5W/5W, 273K/273K, Horizontal, No TEC Control)




- In most cases, MLHP start successfully without using TECs
- There were a few cases where TECs were used to achieve successful start-ups.



# MLHP Test Results - Star-up (5W/5W, 273K/273K, Condensers Slightly above Evaporators)


ST8 LHP 2/19/2004



- CC2 could not reach a steady temperature and E2 was drying out
- At 11:45, TEC2 was turned on and set at 303K. Loop operated steadily afterwards.



## MLHP Test Results – Starts and Operates on Parasitics




CC1 and CC2: No Control/ 283K/278K/275K/No Control



## MLHP Test Results – Starts and Operates on Parasitics

MLHP - ST8 7/30/2004




CC1 and CC2: No Control/ 288K/ 283K/ 278K/ 280K/ 283K/ 286K/ 288K



# MLHP Test Results – Temperature Control (CC1, CC2, or CC1/CC2 Control Set at 303K, E1/E2 Power Varied)

ST8 LHP 3/3/2004




- Loop operated stably at 303K
  - Alternate CC1 and/or CC2 control at 303K
  - Uneven heat loads at 100W/5W and 5W/100W; rapid power change
  - Uneven sink temperatures; rapid sink cycle between 253K and 293K





# MLHP Test Results – Temperature Control (C1/C2 Sinks = 283K/283K)

ST8 July 2, 2004



- 9:40 – 10:37 No active control of CCs
- 10:37 – 11:48 CC1 and CC2 controlled at 295K
- 11:48 – 13:42 No active control of CCs
- TECs allowed the MLHP to operate at 295K

# MLHP TEC Control Heater Power

## 303K CC2 Set Point

E2 Power (W)	TEC2 Power (W) @263K Sink	TEC2 Power (W) @273K Sink
20	0.3	0.2
40	0.8	0.6
60	2.0	1.5
80	3.2	2.4
100	3.5	2.8
120	3.8	2.6

## Summary and Conclusions

---

- **TECs can be used to enhance LHP start-up success.**
  - Maintain a constant CC set point temperature
  - Lower the CC temperature
  - May eliminate the need for starter heaters
- **TECs can be used to broaden the range for LHP operating temperature control.**
  - Cooling mode: maintain CC temperature at low powers
  - Heating mode: reduce the required control heater power
- **Experimental results with one-evaporator and one-condenser LHP**
  - TEC can maintain the operating temperature within  $\pm 0.3\text{K}$  between heat loads of 0.5W and 100W.
  - TEC requires less than 1W over the entire power range.
- **Experimental results with two-evaporator and two-condenser LHP**
  - TEC can maintain the operating temperature within  $\pm 0.3\text{K}$  between heat loads of 5W and 120W.
  - TEC requires less than 4W over the power range.
  - TEC enables LHP to start and operate with parasitic heat gains alone (no power to the evaporators).